

ASKING FOR ASSISTANCE

Technical Support:

Telephone:

(818) 772-9100
(800) 545-6900

Fax:

(818) 772-9120

Technical Support Hours:

8:00 AM to 5:00 PM Monday thru Friday.

Write To:

Gefen Inc.
c/o Customer Service
20600 Nordhoff St.
Chatsworth, CA 91311 USA

CAT5•6000 is a trademark of Gefen Inc.
Macintosh is a trademark of Apple Computer Inc.

TABLE OF CONTENTS

- 1** Introduction
- 2** How It Works
- 3** CAT5•6000S Front Panel Layout
- 4** CAT5•6000S Back Panel Layout
- 5** CAT5•6000 Back Panel Function Descriptions
- 6** CAT5•6000R Front Panel Layout
- 7** CAT5•6000R Back Panel Layout
- 8** CAT5•6000R Back Panel Functions Descriptions
- 9** CAT5 Cable Length Setup
- 10** Link Cable Wiring Diagrams
- 11** CAT5•6000 - Wiring Diagram
- 12** System Specifications
- 13** Warranty

OPERATION NOTES

READ THESE NOTES BEFORE INSTALLING OR OPERATING THE CAT5•6000 SYSTEM

* Industry standard Category-5 (CAT-5) cables are used to operate CAT5•6000 system. Linking the CAT5•6000 sender and receiver units together requires one CAT-5 cable to extend the first monitor, USB and audio signals. A second CAT-5 cable is required to extend the second monitor signal. A third CAT-5 cable is required to extend RS-232 signals, if you are not using RS-232 you will not require a third CAT-5 cable.

* When two monitors are used in the local and remote locations, the video monitors must be a multi-resolution type. This pertains to monitors placed remotely, and those divided between local and remote locations. The video monitors will not initialize correctly at start-up if they are different types.

* The CAT5•6000 units are housed in a metal box for better RF shielding.

INTRODUCTION

Thank you for purchasing the new ex•tend•it CAT5•6000 series by Gefen, Inc.

The ex•tend•it CAT5•6000 by Gefen allows users the benefits of extending USB, audio, RS232, and video signals beyond the desktop. In a growing number of applications, broadcast stations and production facilities need to locate a computer remotely from the keyboard, mouse, and video monitor. A CPU may need to be shared between several users, for example, or moved to another room because of annoying fan noise.

The CAT5•6000 series can be used to extend computers with noisy fans, printers, hard drives, scanners, cameras, keyboards, mouse, and any other USB or RS232-type device. With the potential to cover the distance of 330 feet, industry standard Category 5 (CAT-5) cables are used for the extension of all the devices. One can connect additional CAT5•6000 series to the same computer, allowing access to the same computer from other locations up to 330 feet apart.

HOW IT WORKS

CONTENTS

The CAT5•6000 system consists of:

- (1) CAT5•6000S sender unit
- (1) CAT5•6000R receiver unit
- (2) 5 VDC power supplies
- (2) Video cables (6FT)
- (1) USB cable (06FT)
- (1) Audio cable (06FT)
- (1) User Manual

HOW IT WORKS

In its most basic application, the CAT5•6000S sender unit resides next to the computer. Supplied with the system, straight VGA, audio, and USB cables connect the computer to the CAT5•6000S sender unit. You can also connect a RS232 cable to the CAT5•6000S sender unit (RS232 cable not included).

The CAT5•6000R receiver unit is placed next to the monitors and device, at the remote location. The monitors and USB devices are connected to the CAT5•6000R similar to the way they are connected to the back of the computer (PC or Macintosh).

Industry standard Category 5 (CAT-5) cables are used to link CAT5•6000S sender and CAT5•6000R receiver units together.

CAT5•6000S FRONT PANEL DESCRIPTIONS




1

FRONT PANEL FUNCTION DESCRIPTIONS

- 1 **Power On Indicator** - Indicates that the unit is on and plugged in.

CAT5-6000S BACK PANEL LAYOUT



CAT5-6000S BACK PANEL FUNCTIONS

- 1 **POWER** - 5 VDC external power supply
- 2 **MONITOR 1** - HD15 output connects to the monitor 1 for local video
- 3 **VIDEO IN 1** - HD15 input from computer
- 4 **MONITOR 2** - HD15 output connects to the monitor 2 for local video
- 5 **VIDEO IN 2** - HD15 input from computer
- 6 **AUDIO IN** - Audio Mini Jack input from computer
- 7 **CAT5 2 Video 2** - RJ-45 input extends video input 2 with CAT-5 cable
- 8 **CAT5 1 VIDEO1/USB/AUDIO** - RJ-45 input extends video, USB and audio signals with CAT-5 cable
- 9 **CAT5 RS232** - RJ-45 input extends RS232 signals with CAT-5 cable
- 10 **RS232 IN** - RS232 input from computer
- 11 **USB IN** - USB Input from computer


CAT5•6000R FRONT PANEL LAYOUT



Front Panel Function Descriptions

- 1 **Brightness 2** - Trim pot settings adjust brightness settings based on cable length
- 2 **Brightness 1** - Trim pot settings adjust brightness settings based on cable length
- 3 **Power On Indicator** - Indicates that the unit is on and plugged in.

CAT5•6000R BACK PANEL LAYOUT




CAT5•6000R BACK PANEL FUNCTIONS

- 1 **POWER** - 5 VDC external power supply
- 2 **VIDEO OUT 1** - HD15 output connecting to the video monitor 1
- 3 **VIDEO OUT 2** - HD15 output connecting to the video monitor 2
- 4 **AUDIO** - Audio Mini Jack
- 5 **USB OUT** - USB Outputs - Connects to USB devices
- 6 **CAT-5 Video 2** - RJ-45 input connects CAT-5 cable to receive extended video signals
- 7 **CAT-5 Video/USB 1** - RJ-45 input connects CAT-5 cable to receive extended video, audio, and USB signals
- 8 **RS-232 IN** - RS232 input connects to RS232 devices
- 9 **CAT-5 RS-232** - RJ-45 input connects CAT-5 cable to receive RS232 signals

CAT5 CABLE LENGTH SETUP

Jumper settings are used to set the focus of the picture and characters to the best possible sharpness. The jumpers in the CAT5•6000R are set at the factory as shown in the diagram below. The first step to adjusting the video is to have the CAT5•6000S and CAT5•6000R connected together with the CAT-5 cable that is going to be used in the installation. Then set your computer to the resolution that you will be using most frequently. Then removing the top of the CAT5•6000R by unscrewing the top two screws on either side of the box. Set the jumpers to the recommended jumper setting based on the length of your CAT-5 cable. If you still see some smearing adjust try moving all the jumper up or down one from the recommended setting. If you see smearing of just one color adjust an individual jumper for the color that is smearing (it can be two colors). Repeat the same steps for monitor 2.

Jumper Settings



Recommended Jumper Settings

Cable

0-132 feet



133-198



199-264 feet




265-330 feet



CAT5 LINK CABLE - WIRING DIAGRAM

RJ-45 Jack



White/Orange

Orange

White/Green

Blue




White/Blue

Green


White/Brown

Brown

RJ-45 Jack



CAT5•6000 WIRING DIAGRAM



SPECIFICATIONS

Video Amplifier Bandwidth	350 MHz
Actual Bandwidth	120 MHz
Input Video Signal	1.2 Volts p-p
Input Sync Signal	5 Volts p-p (TTL)
Horizontal Frequency Range	15-70 KHz
Vertical Frequency Range	30 - 170 Hz
Video In	HD-15
Focus/Brightness Control	25 to 450 FT
Video out	HD-15
Link Connector	RJ-45
USB - "A" Connector	USB Out
USB - "B" Connector	USB Device Input
Power Consumption	15 Watts (max.)
Power Supply	5 VDC (External)
Dimensions Send Unit	16"W x 1 3/4"H x 4"D
Dimensions Receive Unit	8"W x 1 3/4"H x 4"D
Rack Mountable	2 Rack Spaces
Shipping Weight	9 Lbs

WARRANTY

Gefen Inc. warrants the equipment it manufactures to be free from defects in material and workmanship.

If equipment fails because of such defects and Gefen Inc. is notified within one (1) year from the date of shipment, Gefen System will, at its option, repair or replace the equipment, provided that the equipment has not been subjected to mechanical, electrical, or other abuse or modifications.

Equipment that fails under conditions other than those covered will be repaired at the current price of parts and labor in effect at the of repair. Such repairs are warranted for ninety (90) days from the day of reshipment to the Buyer.

This warranty is in lieu of all other warranties expressed or implied, including without limitation, any implied warranty or merchantability or fitness for any particular purpose, all of which are expressly disclaimed.

The information in this manual has been carefully checked and is believed to be accurate. However, Gefen Inc. assumes no responsibility for any inaccuracies that may be contained in this manual. In no event will Gefen Inc., be liable for direct, indirect, special, incidental, or consequential damages resulting from any defect or omission in this manual, even if advised of the possibility of such damages. The technical information contained herein regarding CAT5•6000 features and specifications is subject to change without notice.